G42A



TYPE 1434 DECADE RESISTORS

SER # 3638

Figure 1. Type 1434-N, -QC, and -G Decade Resistor boxes.

SPECIFICATIONS

Long-Term Accuracy: Refer to Table 1. Our general two-year warranty applies to these tolerances unless the resistor is damaged by excessive current. Tolerance shown applies to both resistance increments and total resistance after correction for zero resistance.

TABLE 1

Resistance Per Decade	*Resistance Per Step*	*Accuracy**	*Maximum Current*	*Inductance Per Step*
1 Ω	0.1 Ω	±2.0%	1 A	0.01 μH
10 Ω	1.0 Ω	±0.25%	0.3 A	0.04 μH
100 Ω	10 Ω	±0.07%	160 mA	0.05 μH
1 kΩ	100 Ω	±0.05%	50 mA	0.4 μH
10 kΩ	1 kΩ	±0.05%	16 mA	4.0 μH
100 kΩ	10 kΩ	±0.05%	5 mA	
1 MΩ	100 kΩ	±0.05%	1.6 mA	
100-Ω**	1 Ω/div	±1.0 Ω	200 mA	20 μH***

* At low currents and low frequencies.
**Rheostat, used in Type 1434-QC.
*** Total inductance of rheostat.

Zero Resistance: Approximately 2 mΩ per dial at low frequencies except for the Type 1434-QC for which it is approximately 30 mΩ.

Maximum Current: Refer to Table 1. These values also appear on the panel of each decade box. When maximum current is passed through a decade, the temporary change in value of resistance will be within the accuracy specification. Appreciably higher currents will cause permanent changes.

Temperature Coefficient: Less than ±10 ppm/°C at room temperature, except for the low-valued units where the 0.4%/°C temperature coefficient of the zero resistance must be added.

Switches: Multiple, solid-silver-alloy switches are used to obtain low and stable zero resistance.

Terminals: Jack-top binding posts on standard 3/4-inch spacing. A shield terminal is also provided. The Type 1434-G has lug connections accessible from the rear.

Mounting: All types are installed in small cabinets for bench use. The Type 1434-G, with the addition of mounting hardware, becomes a 3 1/2-inch-high, 19-inch relay-rack unit.

Mechanical Data: Refer to the table below for dimensions, net weight, and shipping weight.

Models	*Width*		*Height*		*Depth*		*Net Weight*		*Shipping Weight*	
	in	*mm*	*in*	*mm*	*in*	*mm*	*lb*	*kg*	*lb*	*kg*
M,N,P,QC	11⅝	298	2¾	70	4¼	110	3	1.4	4	1.9
G (bench)	17⅞	442	3½	89	5	130	6	2.8	7	3.2
G (rack)	19	485	3½	89	3½*	89	6	2.8	7	3.2

* Behind panel.

General Radio Experimenter reference: Vol 39, No. 10, October, 1965.

SECTION 1 INTRODUCTION

1.1 PURPOSE.

The Type 1434 Decade Resistors are laboratory-quality decade boxes designed for laboratory measurement, testing, and development work. Their accuracy, incremental as well as total-value, is adequate for all but the most exacting applications. Their small size and clear readout make them particularly useful in experimental and educational laboratory setups.

1.2 DESCRIPTION.

Table 2 lists the five Decade Resistor instruments in the Type 1434 series. The Types 1434-M, -N, and -P contain five decades of resistance in a small cabinet. The Type 1434-QC has four decades plus a rheostat to provide 1-ohm resolution in a 1-megohm box. The larger Type 1434-G has seven decades and is easily converted into a 3 1/2-inch-high, 19-inch-wide relay-rack unit using the angle brackets and dress strips supplied. This decade box also has lug terminals at the rear, as well as the standard front-panel binding posts.

Six high-quality resistors are used in these decades. The resistors are combined by switching in such a way that the resistance increases by steps, with no discontinuities, just as if 10 resistors were used.

TABLE 2

Catalog Number	Description	Total Resistance	Resistance Per Step	Number of Decades
1434-9714	Type 1434-N Decade Resistor	11,111Ω	0.1Ω	5
1434-9713	Type 1434-M Decade Resistor	111,110Ω	1.0Ω	5
1434-9716	Type 1434-P Decade Resistor	1,111,100Ω	10Ω	5
1434-9576	Type 1434-QC Decade Resistor	1,111,105Ω	1.0Ω/div	4 + rheostat
1434-9707	Type 1434-G Decade Resistor	1,111,111Ω	0.1Ω	7

SECTION 2 OPERATING PROCEDURE

2.1 MOUNTING.

All Type 1434 Decade Resistor boxes are housed in small cabinets for bench use. The Type 1434-G is also supplied with additional mounting hardware for installation in a relay rack. To install the Type 1434-G in a relay rack:



Figure 2. Relay-rack installation of Type 1434-G.

a. Remove the black nylon buttons from the holes at the side panels of the instrument. These buttons are press-fitted and are easily removed with a small screw-driver.

b. Install the 3 1/2-by-7/8-inch adaptor-panel assemblies (A, Figure 2) on each side of the instrument, using the 3/8-inch locking screws (B) supplied. The holes in the side-panel of the instrument are tapped with a 10-32 thread to receive these screws.

c. Mount the assembly in a standard 19-inch relay-rack cabinet, using the 5/8-inch No. 10-32 screws (C) and nylon washers (D) provided.

2.2 REAR CONNECTIONS, TYPE 1434-G.

This decade box has lug terminals at the rear. To make connections, remove the two 4-40 screws and the small rectangular plate from the rear panel. The lug terminals are now accessible for use and connections can be completed.

2.3 READOUT.

The rheostat in the Type 1434-QC has a selector dial with ten 10-ohm increments plus additional readout to 1-ohm per graduation. All other decades in the Type 1434 instruments have clear, easy-to-read dials with numbered steps from 0 to X (X = 10).

SUPPLEMENTARY INSTRUCTIONS

TYPE 1434-B, -X DECADE RESISTORS

Two additional Decade Resistors, the Types 1434-B and -X, are included in the Type 1434 series of instruments. The accompanying table lists the complete line of decade boxes available in this series.

Catalog Number	Description	Total Resistance	Resistance Per Step	Number of Decades
1434-9714	Type 1434-N Decade Resistor	11,111Ω	0.1Ω	5
1434-9713	Type 1434-M Decade Resistor	111,110Ω	1.0Ω	5
1434-9716	Type 1434-P Decade Resistor	1,111,100Ω	10Ω	5
1434-9576	Type 1434-QC Decade Resistor	1,111,105Ω	1.0Ω/div	4 + rheostat
1434-9707	Type 1434-G Decade Resistor	1,111,111Ω	0.1Ω	7
1434-9702	Type 1434-B Decade Resistor	1,111,110Ω	1.0Ω	6
1434-9724	Type 1434-X Decade Resistor	111,111Ω	0.1Ω	6

In general, the instructions for the Types 1434-N thru -G are applicable to the Types 1434-B and -X.

PARTS LIST

REFERENCE NO. Type 1434-B	Type 1434-X	DESCRIPTION	PART NO.
R101 thru R106 (for S101)	—	RESISTOR, Wire-wound, 200 kΩ ±0.035% (100 kΩ/step)	6690-4520
R101 thru R106 (for S102)	R101 thru R106 (for S101)	RESISTOR, Wire-wound, 20 kΩ ±0.035% (10 kΩ/step)	6690-4320
R101 thru R106 (for S103)	R101 thru R106 (for S102)	RESISTOR, Wire-wound, 2 kΩ ±0.035% (1 kΩ/step)	6690-4220
R101 thru R106 (for S104)	R101 thru R106 (for S103)	RESISTOR, Wire-wound, 200 Ω ±0.035% (100 Ω/step)	6690-4170
R101 thru R106 (for S105)	R101 thru R106 (for S104)	RESISTOR, Wire-wound, 19.997 Ω ±0.035% (10 Ω/step)	1434-2090
R101 thru R106 (for S106)	R101 thru R106 (for S105)	RESISTOR, Wire-wound, 2 Ω ±0.1% (1 Ω/step)	1434-2070
J101	J101	BINDING POST, Insulated	0938-3000
J102	J102	BINDING POST, Insulated	0938-3000
J103	J103	BINDING POST, Uninsulated, Ground	0938-3022
S101 thru S105	S101 thru S104	SWITCH, Rotary Wafer	7890-4240
S106	S105	SWITCH, Rotary Wafer	7890-4230
—	S106	SWITCH ASSEMBLY, R101 thru R106 0.2 Ω ±0.35% (0.1 Ω/step)	1434-2000

GENERAL RADIO COMPANY
WEST CONCORD, MASSACHUSETTS 01781

Form 1434-0100-AX
September 1966

Printed in U.S.A.

Digitized by the Internet Archive
in 2025

https://archive.org/details/manualsplus_09235

REF NO.	DESCRIPTION	PART NO.
	TYPE 1434-P	
R101 thru R106	RESISTOR, Wire-wound, 200 kΩ ±0.035% (for S101, 100 kΩ/step)	6690-4520
R101 thru R106	RESISTOR, Wire-wound, 20 kΩ ±0.035% (for S102, 10 kΩ/step)	6690-4320
R101 thru R106	RESISTOR, Wire-wound, 2 kΩ ±0.035% (for S103, 1 kΩ/step)	6690-4220
R101 thru R106	RESISTOR, Wire-wound, 200 Ω ±0.035% (for S104, 100 Ω/step)	6690-4170
R101 thru R106	RESISTOR, Wire-wound, 19.997 Ω ±0.035% (for S105, 10 Ω/step)	1434-2090
J101	BINDING POST, Insulated	0938-3000
J102	BINDING POST, Insulated	0938-3000
J103	BINDING POST, Uninsulated, Ground	0938-3022
S101 thru S105	SWITCH, Rotary Wafer	7890-4240
	TYPE 1434-QC	
R101 thru R106	RESISTOR, Wire-wound, 200 kΩ ±0.035% (for S101, 100 kΩ/step)	6690-4520
R101 thru R106	RESISTOR, Wire-wound, 20 kΩ ±0.035% (for S102, 10 kΩ/step)	6690-4320
R101 thru R106	RESISTOR, Wire-wound, 2 kΩ ±0.035% (for S103, 1 kΩ/step)	6690-4220
R101 thru R106	RESISTOR, Wire-wound, 200 Ω ±0.035% (for S104, 100 Ω/step)	6690-4170
R107	POTENTIOMETER, Wire-wound, 106.7 Ω ±2.5%* (S105, 1 Ω/div)	0973-4191
J101	BINDING POST, Insulated	0938-3000
J102	BINDING POST, Insulated	0938-3000
J103	BINDING POST, Uninsulated, Ground	0938-3022
S101 thru S104	SWITCH, Rotary Wafer	7890-4240

*Padded with R107A, Resistor, Composition, REC-20BF ±5%, value determined by Laboratory.

	TYPE 1434-M	
R101 thru R106	RESISTOR, Wire-wound, 20 kΩ ±0.035% (for S101, 10 kΩ/step)	6690-4320
R101 thru R106	RESISTOR, Wire-wound, 2 kΩ ±0.035% (for S102, 1 kΩ/step)	6690-4220
R101 thru R106	RESISTOR, Wire-wound, 200 Ω ±0.035% (for S103, 100 Ω/step)	6690-4170

REF NO.	DESCRIPTION	PART NO.
	TYPE 1434-M continued	
R101 thru R106	RESISTOR, Wire-wound, 19.997 Ω ±0.035% (for S104, 10 Ω/step)	1434-2090
R101 thru R106	RESISTOR, Wire-wound, 2 Ω ±0.10% (for S105, 1 Ω/step)	1434-2070
J101	BINDING POST, Insulated	0938-3000
J102	BINDING POST, Insulated	0938-3000
J103	BINDING POST, Uninsulated, Ground	0938-3022
S101 thru S104	SWITCH, Rotary Wafer	7890-4240
S105	SWITCH, Rotary Wafer	7890-4230
	TYPE 1434-G	
R101 thru R106	RESISTOR, Wire-wound, 200 kΩ ±0.035% (for S101, 100 kΩ/step)	6690-4520
R101 thru R106	RESISTOR, Wire-wound, 20 kΩ ±0.035% (for S102, 10 kΩ/step)	6690-4320
R101 thru R106	RESISTOR, Wire-wound, 2 kΩ ±0.035% (for S103, 1 kΩ/step)	6690-4220
R101 thru R106	RESISTOR, Wire-wound, 200 Ω ±0.035% (for S104, 100 Ω/step)	6690-4170
R101 thru R106	RESISTOR, Wire-wound, 19.997 Ω ±0.035% (for S105, 10 Ω/step)	1434-2090
R101 thru R106	RESISTOR, Wire-wound, 2 Ω ±0.10% (for S106, 1 Ω/step)	1434-2070
J101	BINDING POST, Insulated	0938-3046
J102	BINDING POST, Insulated	0938-3046
J103	BINDING POST, Uninsulated, Ground	0938-3022
S101 thru S105	SWITCH, Rotary Wafer	7890-4240
S106	SWITCH, Rotary Wafer	7890-4230
S107	SWITCH ASSEMBLY, R101 thru R106, 0.2 Ω ±0.35% (0.1 Ω/step)	1434-2000

www.manualsplus.com
1023002

GENERAL RADIO COMPANY
WEST CONCORD, MASSACHUSETTS 01781

*NEW ENGLAND: 22 Baker Avenue, West Concord, Massachusetts 01781
*METROPOLITAN NEW YORK: Broad Avenue at Linden, Ridgefield, New Jersey 07657
PHILADELPHIA: Fort Washington Industrial Park, Fort Washington, Pennsylvania 19034
*WASHINGTON and BALTIMORE: 11420 Rockville Pike, Rockville, Maryland 20852
ORLANDO: 113 East Colonial Drive, Orlando, Florida 32801
SYRACUSE: Pickard Building, East Molloy Road, Syracuse, New York 13211
CLEVELAND: 5579 Pearl Road, Cleveland, Ohio 44129
*CHICAGO: 6605 West North Avenue, Oak Park, Illinois 60302
*DALLAS: 2600 Stemmons Freeway, Suite 210, Dallas, Texas 75207
*LOS ANGELES: 1000 North Seward Street, Los Angeles, California 90038
SAN FRANCISCO: 1186 Los Altos Avenue, Los Altos, California 94022
MONTREAL: 1255 Laird Boulevard, Town of Mount Royal, Quebec, Canada
*TORONTO: 99 Floral Parkway, Toronto 15, Ontario, Canada

*Repair services are available at these offices.

GENERAL RADIO COMPANY (Overseas), 8008 Zurich, Switzerland
GENERAL RADIO COMPANY (U.K.) LIMITED, Bourne End, Buckinghamshire, England
Representatives in Principal Overseas Countries

Form 1434-0100-A
January 1966

Printed in U.S.A.